

# ZT-100-C Water Cut Meter — Quick Start

Quick Start - Zelentech

**Manufacturer:** Zelentech

**Product:** ZT-100-C Digital Water Cut Meter

**Firmware covered:** CAP card 0.16.37-cap-b38 · SIGNAL card 0.17.35-sig-c59

**Document:** QS-ZT100C-100, Issue 1.0, August 2026

---

## Contents

---

|                                              |    |
|----------------------------------------------|----|
| Before You Start                             | 3  |
| Terminal Block                               | 4  |
| Step 1 — Connect the supply                  | 5  |
| Step 2 — Connect the 4-20 mA loop            | 6  |
| Step 3 — Connect the console (recommended)   | 7  |
| Step 4 — Power up and read the LEDs          | 8  |
| Step 5 — Talk to the meter                   | 9  |
| Step 6 — Set the output range                | 10 |
| Step 7 — Set damping if the process is noisy | 11 |
| Step 8 — Verify the loop                     | 12 |
| Step 9 — Confirm a sensible reading          | 13 |
| What Next                                    | 14 |

## Before You Start

This guide takes a new ZT-100-C from unpacking to a live water cut reading, in nine steps. It is the short path. For anything beyond it — day-to-day operation, calibration, troubleshooting — see the **User Manual**.

**Allow about 45 minutes**, not counting the process work of fitting the probe.

### What you need

| Item                                                            | Note                                                             |
|-----------------------------------------------------------------|------------------------------------------------------------------|
| <b>24 V DC supply</b> , regulated                               | The meter draws well under 1 A                                   |
| <b>Screwdriver</b> , small slotted                              | The terminals are screw clamp                                    |
| <b>Twisted pair cable</b> , up to 0.82 mm <sup>2</sup> (AWG 18) | For the loop and for RS485                                       |
| <b>A USB-to-RS485 adapter</b> and a PC                          | Strongly recommended — it is how you verify the meter is healthy |
| A terminal program                                              | 115200 baud, 8N1, no flow control                                |

### What is inside

Two cards share the enclosure and one internal bus:

- **CAP** measures — probe, temperature, the water cut calculation, all calibration data.
- **SIGNAL** outputs — the 4-20 mA loop, HART, the operator console.

SIGNAL displays what CAP measures. **If CAP stops, SIGNAL drives the 3.6 mA alarm within about 2.5 seconds.** That is correct behaviour, and you will see it briefly at every power-up.

### Where you work

The enclosure has **two compartments**. You work in the **connection compartment** only — that is where the 10-position terminal block is.

**Do not open the electronics compartment.** The cards are factory wired and plug together. There is nothing in there to connect, and nothing you need for commissioning.

## Terminal Block

---

All field wiring lands on these ten terminals.

| Terminal | Function                | Wire colour |
|----------|-------------------------|-------------|
| 0        | 4-20 mA <b>IN</b> (+)   | Red         |
| 1        | 4-20 mA <b>IN</b> (–)   | Black       |
| 2        | Internal RS485 <b>A</b> | Grey        |
| 3        | Internal RS485 <b>B</b> | Purple      |
| 4        | 4-20 mA (–)             | Blue        |
| 5        | 4-20 mA (+)             | Green       |
| 6        | External RS485 <b>B</b> | Orange      |
| 7        | External RS485 <b>A</b> | Yellow      |
| 8        | <b>24 VDC (–)</b>       | White       |
| 9        | <b>24 VDC (+)</b>       | Brown       |

You will use **four** of them: 8 and 9 for power, 5 and 4 for the loop. Add 7 and 6 if you are connecting a console, which we recommend.

**Wire by terminal number, not by colour.** Terminals 2 and 3 are the factory-wired bus between the two cards — leave them alone. Terminals 0 and 1 feed a display card that is not released; leave them unconnected.

## Step 1 — Connect the supply

---

**Supply off.** Land the supply on terminals **9 (+)** and **8 (–)**.

### **Check polarity twice**

The regulators are protected against reversed polarity. **The 4-20 mA output stage is not.** Reversing the supply will stop the meter from starting and risks damaging the loop driver.

Terminal **9 is positive**. Terminal **8 is negative**.

Do not switch on yet.

---

## Step 2 — Connect the 4-20 mA loop

---

Land the loop on terminals **5 (+)** and **4 (-)**.

### **DO NOT APPLY A LOOP SUPPLY**

**The meter powers its own loop.** The receiving system must present a passive load — a sense resistor or an analog input — and must **not** apply its own supply to terminals 5 and 4.

**Keep the total loop burden at 500  $\Omega$  or less.** That covers a standard 250  $\Omega$  HART sense resistor plus normal cable and input burden with room to spare.

**If you intend to use HART**, the loop needs a defined impedance, nominally **250  $\Omega$** . It is **not fitted inside the meter** — it is part of your loop. Many control-system inputs already include one.

---

## Step 3 — Connect the console (recommended)

---

Land the RS485 pair on terminals **7 (A)** and **6 (B)**.

This is a **two-wire connection**. There is no signal-common terminal, so run a twisted pair, keep it reasonably short, and if you use shielded cable, earth the shield at the **control-system end only** — there is no shield landing point inside this enclosure.

The meter is permanently terminated at 120  $\Omega$ , so it is always an end of the bus. Do not fit another terminator at the meter, and do not install it as a middle node on a multi-drop segment.

## Step 4 — Power up and read the LEDs

---

Switch the supply on and look at the **red heartbeat LED on both cards**, if you can see them with the compartment open.

| Pattern                                  | Meaning                                       |
|------------------------------------------|-----------------------------------------------|
| <b>2 flashes</b> , pause — on both cards | <b>Normal.</b> The pair is talking            |
| <b>1 flash</b> , pause                   | That card is alone — it cannot hear the other |
| <b>Fast continuous flicker</b>           | The card is about to reset                    |

**Two flashes on both cards is what you want.**

The loop will sit at **3.6 mA** for the first moments after power-up, until CAP's first measurement reaches SIGNAL. This is normal.

---



## Step 5 — Talk to the meter

---

Open your terminal program at **115200 baud, 8N1**, no flow control. Press Enter and type:

```
sys version
```

You should get the product name and firmware version back.

**Nothing, or garbled characters? Swap the two data wires** on terminals 7 and 6 and try again. Reversed A/B is by far the most common commissioning fault on this product — it is the first thing to try, not the last.

Also check: local echo on in your terminal (the meter never echoes your keystrokes, so a silent screen proves nothing), and 115200 rather than 9600.

Now check the pair:

```
cap
```

This shows link health and every measured value with its quality. You want the peer count at **1** and the values reading **good**.

---

## Step 6 — Set the output range

`pv.range` is the water cut percentage that corresponds to 20 mA. 4 mA is always 0 %.

```
auth commission 1234
cfg set pv.range 10
```

| <code>pv.range</code> | 20 mA means    | Resolution      |
|-----------------------|----------------|-----------------|
| 25 % (default)        | 25 % water cut | 1.5625 % per mA |
| 10 %                  | 10 % water cut | 0.625 % per mA  |
| 5 %                   | 5 % water cut  | 0.3125 % per mA |

**Choose the smallest range that comfortably covers your process.** A narrower range gives better resolution on the loop, but saturates sooner — above range the output pins at 20.4 mA.

Takes effect immediately, no reboot.

## Step 7 — Set damping if the process is noisy

---

Damping smooths the reading. It lives on the **measuring card**, so it is set through the `cap` prefix, and it affects the console, the loop and HART alike.

```
cap cfg set meas.damping 5
```

Range **0 to 60 seconds; 0 is the shipped default**, and no password is needed: a command forwarded with `cap` reaches the measuring card already authorised. Start at 0 and add damping only if the reading is restless. Damping slows the response to real process changes just as much as to noise.

---

## Step 8 — Verify the loop

---

Drive known currents and check them at the receiving end:

```
out test 4  
out test 12  
out test 20  
out auto
```

Each `out test` holds for **30 seconds** and then returns to normal by itself. `out auto` returns immediately.

If your reference meter disagrees, the output can be trimmed — see *Output trim* in the User Manual. Do not adjust anything else to compensate for a loop reading.

---

## Step 9 — Confirm a sensible reading

---

With the probe fitted and wetted by the process:

```
cap meas read
```

Check that:

- **wcut** reads plausibly and is **good**
- **temp\_proc** is near process temperature and is **good** — **fault** means the PT100 is not connected, and the meter will substitute 25 °C and keep running at reduced accuracy
- **cap\_pf** is **good**

**The meter is now running.** Its factory calibration is in place.

---

## What Next

---

**Before you trust the number**, calibrate against a laboratory sample — the meter's factory calibration does not know your crude. See *Field Calibration* in the User Manual.

| If you want to                           | See, in the User Manual      |
|------------------------------------------|------------------------------|
| Read and interpret the output day to day | <i>Reading the Water Cut</i> |
| Calibrate against a laboratory result    | <i>Field Calibration</i>     |
| Understand 3.6 mA and 20.4 mA            | <i>Special currents</i>      |
| Connect a HART master                    | <i>HART Connection</i>       |
| Diagnose a problem                       | <i>Troubleshooting</i>       |

### Two things worth knowing now

**3.6 mA means something.** This firmware drives the alarm current when the measurement is stale or faulted — it does not freeze at the last good value the way the previous generation did. Configure your control system to treat anything below 3.8 mA as a fault, not as a low water cut.

**Every value carries a quality.** `good`, `stale`, `fault` and the rest are printed beside each reading. A missing or faulted sensor is always stated, never dressed up as a live number.